

# Kirby Jumbo Task

## Operating Instructions



### 1. Ratchet Operated Backrest Height

Lift backrest to adjust incrementally. At top of adjustment, backrest will reset to bottom position.



### 2. Back Rake Adjustment Lever

Pull up to adjust back rake (angle), push down again to lock in place.



### 3. Seat Tilt Adjustment Lever

Pull up to adjust seat tilt, push down again to lock in place.



### 4. Seat Height Adjustment Lever

Pull up and hold to adjust seat height, release once height is set.



### 8. Arm Rest Height Adjustment Button

Press and hold to adjust armrest height, release once height is set.




### 7. Seat Depth Adjustment Lever

Pull up and hold to adjust seat depth; seat will slide forwards/backwards. Release once depth is set.



### 6. Seat Tilt Tension Adjustment Dial

Turn clockwise / anti-clockwise to adjust tension in seat tilting mechanism.



### 5. Inflatable Lumbar Support

Squeeze pump (A) to inflate lumbar support, press button (B) to deflate.

